

Fitting Instructions – AGB CYLINDERS

AGB CYLINDERS – KEY TO TURN CYLINDERS

Date Modified: 27/03/2023

Last modified by: Brock Hutchins

For best results when fixing an AGB Key to Turn Cylinder follow these instructions.

Atlantic UK recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

- X1 Cylinder
- X3 Keys for 5 pin, X5 for 15 pin.
- X1 Machine screw

Tools needed

- Hand Screwdriver with suitable tip.
- 1) First, place the cylinder into the precut aperture in the door, lining up the threaded hole in the cylinder with the hole in the forend of the lock
 - 2) Second, insert the machine screw into the lock body and line up with the hole in the cylinder.
 - 3) Tighten the screw until you feel resistance, **DO NOT USE A DRILL OR IMPACT DRIVER, YOU MUST USE A HAND SCREWDRIVER.**